Customizing Your Lexus

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.
Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	Customized setting
Smart access system with push-button start	Smart access system with push-button start	ON	OFF
	Operation signal (Emergency flashers)	ON	OFF
	Operation signal (Buzzer)	ON	OFF
Wireless remote control	Unlocking operation	Driver's door unlocked in 1-step, all doors unlocked in 2-steps	All doors unlocked in 1-step
	Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	OFF
			30 seconds
			120 seconds
	Operation signal (Emergency flashers)	ON	OFF
	Operation signal (Buzzer)	ON	OFF
	Trunk unlocking function	ON	OFF
	Trunk unlocking operation	Push and hold	Push twice
			One short push
	Panic function	ON	OFF
	Buzzer sounds when pushing with any door not closed	ON	OFF

Item	Function	Default setting	Customized setting
Door lock	Unlocking using a key	Driver's door unlocked in 1-step, all doors unlocked in 2-steps	All doors unlocked in 1-step
	Speed-detecting automatic door lock function	OFF	ON
	Opening driver's door unlocks all doors	OFF	ON
	Shifting the shift lever to "P" unlocks all doors.	ON	OFF
	Shifting the shift lever to position other than "P" locks all doors	ON	OFF
Power windows	Linked door key operation	Open and close	Open only
			Close only
	Wireless remote control linked operation	OFF	Open

Item	Function	Default setting	Customized setting
Moon roof	Linked door key operation	Open and close	Open only
			Close only
	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote control linked operation *1	OFF	Open
	Linked operation of components when wireless remote control used *1	OFF	Slide only
			Tilt only
Automatic light control system	Light sensor sensitivity	Level 3	Levels 1 to 5
	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds
			60 seconds
			90 seconds
	Day time running light	ON	OFF *2
Windshield wipers and washer	Switching operation when the vehicle is stationary	ON	OFF
	Drip prevention function	ON	OFF
	Time elapsed before the drip prevention function operates	Variable depending on the vehicle speed	3 seconds

*1: This function cannot be customized unless power window operation using the wireless remote control is enabled.

*2: Vehicles sold outside Canada

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="11">Illumination</td><td rowspan="2">Time elapsed before lights turn off</td><td rowspan="2">15 seconds</td><td>7.5 seconds</td></tr>
<tr><td>30 seconds</td></tr>
<tr><td>Operation when the doors are unlocked</td><td>ON</td><td>OFF</td></tr>
<tr><td>Operation after the “ENGINE START STOP” switch turned OFF</td><td>ON</td><td>OFF</td></tr>
<tr><td rowspan="2">Front/rear personal lights turned on when a door is opened</td><td rowspan="2">Correspond-ing light only</td><td>All lights</td></tr>
<tr><td>OFF</td></tr>
<tr><td>Foot lights</td><td>ON</td><td>OFF</td></tr>
<tr><td>Shift lever light</td><td>ON</td><td>OFF</td></tr>
<tr><td>Outer foot light</td><td>ON</td><td>OFF</td></tr>
<tr><td>Front/rear personal lights turned on when the interior lights are switched “ON”</td><td>ON</td><td>OFF</td></tr>
<tr><td></td><td></td><td></td></tr>
<tr><td rowspan="3">Rear sunshade</td><td rowspan="3">Time elapsed before the reverse operation feature acti-vates</td><td rowspan="3">0.7 seconds</td><td>0 seconds</td></tr>
<tr><td>0.9 seconds</td></tr>
<tr><td>1.2 seconds</td></tr>
</table>

Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

- **U.S. OWNERS**
  - In the U.S. mainland or Canada:
    Lexus Roadside Assistance
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
  - In Hawaii:
    Servco Automotive Roadside Assistance/Customer Services
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- **CANADIAN OWNERS**
  - In Canada or the U.S. mainland:
    Lexus Roadside Assistance/Customer Service
    1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: **www.lexus.com**
- Hawaii: **www.servcolexus.com**
- Canada: **www.lexus.ca**

©2009 TOYOTA MOTOR CORPORATION
All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.